

87 Reservoir Installation Instructions

This reservoir is for use with our Bliss 60 Kit and Water Wing Kit.





Dig the hole in preparation for the reservoir installation. Approximately 46 cm deep from the top of ground level down. See Diagram A.

Note if paving is required to over lap or be higher than the grill simply increase the hole depth by the cm's required.

The concrete footing base must be level and should be a minimum of 12cm deep. Allow the concrete footing base to dry for **24 hours**. A thin layer of sand on the concrete footing will protect the reservoir from puncturing.

Set up the reservoir so that the top of the reservoir and grill is level required surrounding ground or paving. A little extra sand can help bring up the level if required. See Diagram B.

Fill the reservoir with water before backfilling around the outside with concrete. This will prevent the reservoir from moving before the concrete dries. See diagram C.



Important Notes:-

Allow the concrete footing base to dry for **24 hours**. Wet concrete mix must be used when back filling to ensure the concrete fills up and under the reservoir lip. This is to help support the weight of the water feature. See Diagram C1. We recommend running the pump cable through an under ground pipe from the feature to the power supply.

WARNING NOTE. Stone features are heavy. Take extra care when moving them.

