

Belmont Reservoir Installation Instructions

This reservoir is for use with our Belmont Ball with Plinth kits.

Dig the hole in preparation for the reservoir installation. Approximately 54.5 cm deep from the top of ground/paving finished level.

The concrete footing base must be level and should be 12cm deep. Allow the concrete footing base to dry for **24 hours**. A thin layer of sand on the concrete footing will protect the reservoir from puncturing. See Diagram A.

Set up the reservoir so that the stone plinth is level with your required surrounding ground or paving. A little extra sand can help bring up the level if required. See Diagram B.

Fill the reservoir with water before backfilling around the outside with wet concrete. This will prevent the reservoir from moving before the concrete dries. See diagram C.

The pump can be adjusted to change the flow rate of the water.

Important Notes:-

Allow the concrete footing base to dry for **24 hours**.

Wet concrete mix must be used when back filling to ensure the concrete fills up and under the reservoir lip. This is to help support the weight of the water feature.

We recommend running the pump cable through an under ground pipe from the feature to the power supply.

WARNING NOTE. Belmont spheres are **heavy**. Take extra care when moving them.

Ensure cable cut out is positioned close to the location where you wish the power cable to exit i.e. underground pipe.

